

## **Filters vervangen – WTW-installatie (Zehnder ComfoAir Standaard 300)**

Goede ventilatie is belangrijk voor een gezond binnenklimaat. Vervang daarom de filters regelmatig.

### **Wanneer?**

Elke **2 tot 3 maanden**, of als het toestel een filtermelding geeft. De filters kunt u de eerste twee keren voorzichtig stofzuigen en/of uitkloppen. Daarna zal het filter vernieuwd moeten worden.

### **Zo vervang je de filters**

#### **1. Zet het toestel uit**

Dit doet u door de stekker uit het stopcontact te halen.

#### **2. Open de filter kleppen**

Trek de grijze kleppen voorzichtig open.

#### **3. Haal de oude filters eruit**


Trek beide filters rustig naar voren.

#### **4. Maak de binnenkant schoon**

Stofzuig los vuil en veeg de ruimte schoon met een droge doek.

#### **5. Plaats de nieuwe filters**

Schuif de nieuwe filters op dezelfde plek terug.

 Let op eventuele pijltjes voor de **luchtstroomrichting**.

**Let op; het filterframe is niet benodigd bij de nieuwe filters. Deze kunt u zonder frame direct in de unit plaatsen.**

#### **6. Sluit de kleppen en zet het toestel weer aan**

Druk deze goed aan totdat je een 'klik' hoort.

#### **7. Reset de filtermelding**

De melding "Filter" geeft aan dat de filters vervangen moeten worden zoals in bovenstaande stappen is omschreven. Om deze melding weg te krijgen, kunt u de OK-toets minimaal 5 sec ingedrukt houden.

Op de schakelaar (RFZ) is ook zichtbaar dat er een filter melding is. Hier knipperen dan de leds 3x rood.

#### **8. Belangrijk**

- Zet de ventilatie unit altijd uit bij het wisselen van de filters
- Was filters **niet** uit en gebruik ze niet opnieuw.
- Een schoon filter zorgt voor **betere lucht, minder stof en een stiller toestel**.



## Replacing filters – Zehnder ComfoAir Standard 300

Good ventilation is important for a healthy indoor climate. Therefore, replace the filters regularly.

### When?

Every **2 to 3 months**, or when the unit shows a filter warning. The first two times, you can carefully vacuum and/or gently tap out the filters. After that, the filters must be replaced.

### How to replace the filters

#### 1. Switch off the unit

Unplug the unit from the power socket.

#### 2. Open the filter covers

Carefully pull open the grey covers.

#### 3. Remove the old filters


Gently pull both filters forward.

#### 4. Clean the inside

Vacuum loose dirt and wipe the compartment with a dry cloth.

#### 5. Insert the new filters

Slide the new filters back into the same position.

 Pay attention to any arrows indicating the **airflow direction**.



**Note:** the filter frame is not needed with the new filters. You can place them directly into the unit without the frame.

#### 6. Close the covers and switch the unit back on

Press them firmly until you hear a “click”.

#### 7. Reset the filter warning

The message “Filter” indicates that the filters need to be replaced as described above. To clear this message, press and hold the OK button for at least 5 seconds.

On the switch (RFZ), the filter warning is also visible: the LEDs will flash red 3 times.

#### 8. Important

- Always switch off the ventilation unit before replacing the filters.
- Do **not** wash filters or reuse them.
- A clean filter **ensures better air quality, less dust, and a quieter unit.**